ETHERNET TO HDMI CONVERTER USER MANUAL



V1.0

March 2024

screen.

Thank you for purchasing SIYI's product.

SIYI AI tracking module supports collaborative control with SIYI optical pods and gimbal cameras to achieve real-time tracking and capture of targets and can highlight the tracking target in the picture through real-time focus and zoom. It supports the anti-lost function. During the tracking process, if the target is blocked or briefly leaves the monitoring screen, AI tracking module can automatically recognize and continue tracking when it re-enters the monitoring

To ensure you a good experience of the product, please read this manual carefully. If you encounter any issue using the product, please consult the manual or check the online pages of this product on SIYI official website (https://siyi.biz/en). You can also write an email to SIYI official A/S center (support@siyi.biz).

2

SIYI User Group - Facebook



SIYI Official Website (https://siyi.biz/en)

SIYI Official Store (<u>https://shop.siyi.biz</u>)

SIYI Official AliExpress Store (<u>https://siyi.aliexpress.com</u>)

SIYI YouTube Channel (<u>https://www.youtube.com/c/SIYITech</u>)

User Manual Update Log

| Version | Date | Updates |
|---------|---------|-------------------|
| 1.0 | 2023.11 | Original version. |

SIYI

CONTENT

| READ TIPS | 1 |
|--|----|
| Icons | 1 |
| Safety | 1 |
| Storage / Carrying / Recycling | 2 |
| 1 INTRODUCTION | 3 |
| 1.1 Product Features | 3 |
| 1.2 Interface & Pinouts | 4 |
| 1.3 Technical Specification | 5 |
| 1.4 Packing List | 6 |
| 1.5 Indicator Definition | 7 |
| 2 TYPICAL CONNECTION DIAGRAM | 8 |
| 2.1 SIYI Optical Pod Outputs HDMI Video through Ethernet to HDMI Converter | 8 |
| 2.2 HM30 Ground Unit Outputs HDMI Video through Ethernet to HDMI Converter | 9 |
| 3 HOW TO CONFIGURE THE MODULE | 10 |
| 3.1 IP Addresses | 11 |
| 3.1.1 Check IP Addresses | 11 |
| 3.1.2 Change IP Addresses | 11 |
| 3.2 Configuration | 13 |
| 3.2.1 Check Converter Configuration | 13 |
| 3.2.2 Make Converter Configuration | 14 |
| 3.3 Firmware Upgrade | 15 |
| 3.3.1 Check Firmware Version | 15 |
| 3.3.2 Firmware Upgrade Steps | 15 |
| 3.4 Common IP Addresses | 17 |
| 3.5 Main Firmware Update Log | 19 |
| 4 After-sale Service | 20 |
| 4.1 Repair Service | 21 |
| 4.2 Warranty | 22 |
| 4.2.1 7-Day Return & Refund | 22 |
| 4.2.2 15-Day Replacement | 23 |

SIYI

| 4.2.3 1-Year Warranty Repair | · | 25 |
|------------------------------|---|----|
|------------------------------|---|----|

Ethernet to HDMI Converter User Manual v1.0

READ TIPS

lcons

Please pay more attention to content indicated with the following marks:

DANGER Dangerous manipulation probably leads to human injuries.
 WARNING Warnings on manipulation possibly leads to human injuries.
 CAUTION Cautions on what manipulation may lead to property loss.



Safety

SIYI ethernet to HDMI converter is designed for professional application in specific scenes, users who approach to the equipment should have the basic knowledge of how to operate it. Irregular or irresponsible manipulations to the device may cause damage, property loss, or human injuries, and SIYI Technology is not obliged to any of the damage, loss, or injury. It is prohibited to use SIYI products for military purpose. Users under 14 years' old should follow an experienced trainer's guide. Disassembling or modification to the system is prohibited without permission from its manufacturer, SIYI Technology.

Storage / Carrying / Recycling

When your SIYI product is left unused, or you are bringing it outdoors, or the product life has expired, please do read the below precautions.

🗥 DANGER

Always place your SIYI products at places where babies or kids do not reach.

SIYI products should be placed in places which are too hot (above 60°C) or too cold (under -20°C).

CAUTION

SIYI products should not be placed in places under direct sunshine or too dusty or too wet. Carrying or transporting SIYI products should avoid vibration or shatter by which components may break.

SIYI 1 INTRODUCTION

1.1 Product Features

Mavlink OSD Information Overlay

Mavlink telemetry information from SIYI links can be overlay to HDMI video output as On-Screen-Display (OSD) through the Ethernet to HDMI output converter. FPV OSD coming with full HD images is very enjoyable.


Real-Time Recording in MP4 Format

The converter can record video streams to TF / SD card in MP4 format. Very easy to replay flight videos and make backup.

Abundant Configuration

Through TF / SD card the converter can also be configured for customizing IP addresses, modifying video stream RTSP addresses, enable / disable OSD, etc. Tiny module, powerful feature!

1.2 Interface & Pinouts



1.3 Technical Specification

| Video Input Port | Ethernet |
|--------------------------------|--|
| Video Output Port | Micro-HDMI |
| Working Voltage | 8.4 ~ 25.2 V |
| Power Consumption | Average: 1.5 W Summit: 5 W |
| Video Recording Resolution | 1080p (1920*1080) @ 30 fps 720p (1280*720) @ 30 fps |
| Video Recording Bitrate | 12 Mbps |
| Supported File System | FAT32 ExFAT |
| Video Recording Format | MP4 |
| Supported TF / SD Card Type | Micro-SD Class10, max 128 GB |
| Product Dimensions | 42 x 37 x 13 mm |
| Product Weight | 25 g |
| Working Temperature | -10 ~ 50 ℃ |

Mark

Please format the SD card to FAT32 before firmware upgrade.

1.4 Packing List

1 x SIYI Ethernet to HDMI Converter

1 x HM30 Ground Unit to Ethernet-HDMI Converter 2 in 1 Connection & Power Cable (Connect HM30 ground unit's LAN port to the converter's Ethernet port and powers the converter separately)

1 x Micro-HDMI to Standard HDMI Cable (Connect the converter to HDMI monitor)

1 x SIYI Optical Pod to Ethernet-HDMI Converter 2 in 1 Connection & Power Cable (Connect SIYI optical pod's Ethernet port to the converter's Ethernet port and powers the converter separately)

SIYI

1.5 Indicator Definition

• Red-Green-Yellow Slow Blinks: Converter is starting.


Slow Green Blinks: Converter receives video stream.

O Slow Yellow Blinks: Converter is not receiving video stream.

SIYI **2 TYPICAL CONNECTION DIAGRAM**

2.1 SIYI Optical Pod Outputs HDMI Video through Ethernet to HDMI

Converter



2.2 HM30 Ground Unit Outputs HDMI Video through Ethernet to HDMI Converter



3 HOW TO CONFIGURE THE MODULE

SIYI Ethernet to HDMI converter can be configured through SD card, so does firmware upgrade.


O Mark

SIYI

It is suggested to format the SD card to FAT32 before firmware upgrade.

It is suggested to insert the SD card to the converter and run it for a while, then you will see the files related to module configuration.

The two ".txt" files in the root category of the SD card are for checking and changing module configuration.



"curip.txt" for checking the current IP addresses.

"setip.txt" for customers to change IP addresses.

3.1 IP Addresses

3.1.1 Check IP Addresses

Open the "curip.txt" file, you will see the current IP addresses and gateway of the AI tracking module.

[NET_CONFIG] IP = 192.168.144.50 GATEWAY = 192.168.144.12

"192.168.144.50" is the factory default module IP addresses.

"192.168.144.12" is the factory default module gateway.

3.1.2 Change IP Addresses

Open the "setip.txt" file, input the IP addresses you need after "IP = ".

SIVI

Then insert the SD card to the module and power it. After three to five minutes, the new IP addresses will be flashed into module. Then we restart the module to finish changing IP addresses.



When you are using the converter with SIYI gimbals and SIYI links, please do configure its IP addresses within "192.168.144.X" and avoid conflicting with their existing IP addresses. Please refer to the "Common IP Addresses" chapter in this manual for detail.

3.2 Configuration

3.2.1 Check Converter Configuration

Open the "curip.txt" file, you will see the current configuration of the converter.

```
[Protocol]
ProtocolType = 1
RtspAddress = rtsp://192.168.144.25:8554/main.264
SiyiAddress = 192.168.144.25
SiyiPort = 37256
OsdShow = 1
```

- ProtocolType = 1 indicates the current streaming type (0 = SIYI protocol, 1 = RTSP stream)
- RtspAddress = rtsp://192.168.144.25:8554/main.264 indicates the current steam source's RTSP addresses
- SiyiAddress = 192.168.144.25 indicates the current stream source's SIYI protocol IP addresses
- SiyiPort = 37256 indicates the current stream source's SIYI client port number
- OsdShow = 1 indicates current OSD displaying status (0 = OFF, 1 = ON)

3.2.2 Make Converter Configuration

Open the "setip.txt" file, input your required parameters after relevant configurations.

[Protocol] ProtocolType = RtspAddress = SiyiAddress = SiyiPort = OsdShow =



Configuring the converter does not require restarting it. When the converter is working, parameters will be automatically flashed in after inserting Micro-SD card.

3.3 Firmware Upgrade

3.3.1 Check Firmware Version

Open the "curip.txt" file, you will see the current firmware version of the AI tracking module.

文件(F) 编辑(E) 格式(O) [FW_VERSION] Version = 0.1.11

3.3.2 Firmware Upgrade Steps

Before upgrading, it is necessary to prepare the tools, software, and firmware below.

• SD / TF card



Customers should prepare the above tools.

• SIYI Ethernet to HDMI Converter Firmware

SIVI



Above tools can be downloaded from the "Downloads" page on SIYI official website (https://siyi.biz/en).

Steps

1. Save the module firmware's ".bin" file to the SD / TF card's root directory and do not change the file name.

| | 修改日期 | 类型 |
|------------------------------|------------------|--------|
| SIYI_LanToHDMI_UpgradeSD.bin | 2023/10/11 11:16 | BIN 文件 |

- 2. Insert the SD card with saved firmware to the converter and power it.
- 3. Wait for three to five minutes, camera firmware will be flashed automatically and disappear from the SD card.
- 4. Restart the module to make the configuration work.

SIYI

3.4 Common IP Addresses

- SIYI Air Unit IP Address: 192.168.144.11
- SIYI Ground Unit IP Address: 192.168.144.12
- SIYI Handheld Ground Station Android System IP Address: 192.168.144.20

SIYI Ethernet to HDMI Output Converter IP Add: 192.168.144.50

SIYI AI Camera IP Address: 192.168.144.60

SIYI Optical Pod / Gimbal Camera's Default IP Addresses: 192.168.144.25

(NEW) SIYI Optical Pod / Gimbal Camera's Default RTSP Addresses:

- SIYI AI Camera: rtsp://192.168.144.25:8554/video0
- Main Stream: rtsp://192.168.144.25:8554/video1
- Sub Stream: rtsp://192.168.144.25:8554/video2

(NEW) SIYI FPV App's Private Video Stream Protocol's Addresses:

- SIYI Camera 1 Main Stream: 192.168.144.25: 37256
- SIYI Camera 1 Sub Stream: 192.168.144.25: 37255
- SIYI Camera 2 Main Stream: 192.168.144.26: 37256
- SIYI Camera 2 Sub Stream: 192.168.144.26: 37255

SIYI IP67 Camera A's IP Address: 192.168.144.25

SIYI IP67 Camera B's IP Address: 192.168.144.26

SIYI Air Unit HDMI Input Converter's IP Address: 192.168.144.25

SIYI IP67 Camera A's RTSP Address: rtsp://192.168.144.25:8554/main.264

2024 SIYI Technology Copyright

SIYI

SIYI IP67 Camera B's RTSP Address: rtsp://192.168.144.26:8554/main.264

SIYI Air Unit HDMI Input Converter's RTSP Address:

rtsp://192.168.144.25:8554/main.264

Common Video Player: SIYI FPV, QGroundControl, EasyPlayer

Network Diagnosis Tool: Ping Tools

O Mark

SIYI cameras released after ZT30 (including ZT30 and ZT6) start to use the new addresses. SIYI cameras released before ZT30 (including ZR30, A2 mini, A8 mini, ZR10, and R1M) are stilling using the old addresses.

3.5 Main Firmware Update Log

| Date | 2023-10-11 |
|---------|---|
| Version | 0.1.11 |
| Updates | New: OSD information changed to English only. |

| Date | 2023-07-18 | |
|---------|-------------------|--|
| Version | 0.1.9 | |
| Updates | Improve: Latency. | |

4 After-sale Service

If there were any questions or problems using SIYI Technology's product, you can always try to send an email to SIYI Official A/S Center (support@siyi.biz) or consult your sales representative or dealer for answers or solutions.

SIYI

4.1 Repair Service

If your purchased SIYI products cannot work properly, please contact SIYI Official A/S Center for consulting.

Usually there are two situations for acquiring repair service.

- Product Defect
- Product Damage

SIYI products under the two situations can be sent back to SIYI for repairing. Defect products with valid warranty can be repaired for free. Defect products without valid warranty or damaged products should be charged of repair fees after repairing. Please refer to SIYI's Official A/S Quotation for detail.

4.2 Warranty

SIYI Technology guarantees that, subject to the following conditions, Return & Refund Service, Replacement Service, and Warranty Repair Service can be requested. Please contact SIYI directly (support@siyi.biz or your sales representative) or authorized SIYI dealer for more detail.

4.2.1 7-Day Return & Refund

You can request Return & Refund Service:

Within seven (7) days of receiving a product if the product has no manufacturing defect, has not been activated and is still in new or like-new condition.

Within seven (7) days of receiving a product if the product has a manufacturing defect.

Return & Refund Service will not be provided where:

It is requested beyond seven (7) calendar days of receiving a product.

A product sent to SIYI for Return & Refund Service does not include all original accessories, attachments or packaging, or any item is not in new or like-new condition, i.e., with cracks, dents, or scratches.

A legal proof of purchase, receipt or invoice is not provided or is reasonably believed to have been forged or tampered with.

Any fault or damage of the product is caused by unauthorized use or modification of the product, including exposure to moisture, entry of foreign bodies (water, oil, sand, etc.) or improper installation or operation.

Product labels, serial numbers, waterproof marks, etc. show signs of tampering or alteration.

Damage is caused to the product by uncontrollable external factors, including fire, floods, high winds, or lightning strikes.

A product is not delivered to SIYI within seven (7) calendar days after Return & Refund Service confirmation is sent from SIYI.

Other circumstances stated in this policy.

4.2.2 15-Day Replacement

You can request Replacement Service:

Within fifteen (15) calendar days of receiving the product if the product has sustained a substantial damage in transit, provided always that the damage proof issued by the carrier can be provided to SIYI.

Within fifteen (15) calendar days of receiving the product if the product does not match the original description of the product in one or more significant respects.

Within fifteen (15) calendar days of receiving the product if the product suffers performance failure.

Replacement Service will not be provided where:

Service is requested more than fifteen (15) calendars days after receiving a product.

Legal proof-of-purchase, receipts, or invoices are not provided, or are reasonably believed to have been forged or tampered with.

A product sent to SIYI for replacement does not include all original accessories, attachments, and packaging, or contains items damaged by user error.

A product is found to have no defects after all appropriate tests are conducted by SIYI.

Any fault or damage of the product is caused by unauthorized use or modification of the product, including exposure to moisture, entry of foreign bodies (water, oil, sand, etc.) or improper installation or operation.

Damage is caused by uncontrollable external factors, including fires, floods, high winds, or lightning strikes.

24

Received product has not been sent back to SIYI seven (7) calendar days after replacement confirmation from SIYI.

Proof of damage during transit issued by the carrier cannot be provided.

Other circumstances stated in this policy.

4.2.3 1-Year Warranty Repair

You can request warranty repair service:

If a product does not function as warranted during the warranty period, you may obtain after-sales service by contacting SIYI's service center. You will need to provide a valid proof-of-purchase, receipt, or order number for the warranty service.

Charges may apply for services not covered by this Limited Warranty. Please contact SIYI for information specific to your location.

Please note that the warranty service is only available in the respective SIYI service regions where you purchased your SIYI product.

Warranty Repair service will not be provided where:

Crashes or fire damage caused by non-manufacturing factors, including but not limited to pilot errors.

Damage caused by unauthorized modification, disassembly, or shell opening not in accordance with official instructions or manuals.

Damage caused by improper installation, in correct use, or operation not in accordance with official instructions or manuals.

Damage caused by non-authorized service provider.

Damage caused by unauthorized modification of circuits and mismatch or misuse of the battery and charger.

Damage caused by operation in bad weather (i.e., strong winds, rain, sand/dust storms, etc.)

Damage caused by operating the product in an environment with electromagnetic interference (i.e., in mining areas or close to radio transmission towers, high-voltage wires, substations, etc.)

Damage caused by operating the product in an environment suffering from interference from other wireless devices (i.e., transmitter, video-downlink, Wi-Fi signals, etc.)

Damage caused by reliability or compatibility issues when using unauthorized third-party parts.

Damage caused by operating the unit with a low-charged or defective battery.

26

SIVI

Products or parts with an altered identification label or from which the identification label has been removed.

SIYI Technology

Business Inquiry: info@siyi.biz

Phone: +86 400 838 2918

A/S Center: support@siyi.biz